



Airtravel with cartridge activated avalanche backpacks (equipped with Alpride System 1.0 or 2.0)

Consider the following tips:

The airline must be informed a minimum **24 hours** before traveling on your request to travel with a cartridge activated avalanche airbag.

Prepare the system for transportation – Unscrew the cartridge and activate the system (pulling the trigger). Screw the cartridges in and close the zipper pocket. Do not transport the cartridges in an uninstalled position! The system is now safe for travelling and protected against accidental activation.

Include a printout of the most recent version of the IATA 2.3A table, including the safety information (MSDS Material Safety Data Sheet, you can find it in our website) regarding our Co2- and Argon-Cartridges with your backpack, the cartridges are approved along the IATA Classification 2.2. We recommend keeping a copy of those with your travel documents.

According to the IATA Table 2.3A the backpack is permitted as in/or carry-on or check-in luggage, **but we recommend traveling as carry-on luggage.**

IMPORTANT: Don't forget to reload the main spring before riding: remove cartridges, reload main spring and screw cartridges into the system.

Prepare the system and the documents following the same procedures for your inbound flight travel.

Links to most updated information and downloads of documents:

IATA Website – Passenger Dangerous Goods Corner

IATA Table 2.3A

Safety information for the CO₂ cartridges used in the Alpride System 1.0/2.0

Safety information for the Argon cartridges used in the Alpride System 1.0/2.0

<https://www.alpride.com/user-manual>